


Fieldpiece

Wireless Clamp Meter

OPERATOR'S MANUAL

Model SC660



Description

The SC660 is the top of the line clamp meter with wireless functionality for the HVACR professional. Receive wireless measurements from Fieldpiece accessory heads and wireless transmitters from anywhere on the jobsite. For instance, receive an indoor delta T temperature measurement wirelessly from a Fieldpiece transmitter while you work at the condenser. Send your electrical measurements to the Job Link™ mobile app via the Fieldpiece JL2 Transmitter. (See Wireless section for more details).

Hang your SC660 clamp meter to any metallic surface with the heavy-duty magnet and when the job is done, snap your test leads in the back case for tidy and convenient storage. See both voltage and amperage readings at the same time on the large dual display, even in low light conditions using the bright blue backlight.

Easily see your amperage readings no matter how you clamp around a wire with the swivel head AAC clamp.

Verify the order of 3-phase voltage lines with just two leads. Capture L1-L2 and L1-L3 to check that motor lines are correctly installed with Phase Rotation test.

Measure the delta T across the evaporator with

dual Type K temperature ports on the SC660.

Take more accurate VAC and AAC readings on variable frequency drives with True RMS sensing technology. Measure the starting amp draw of a compressor with Inrush current mode.

Illuminate the way with a powerful LED built into the clamp jaw. Easily see your measurements with the bright blue backlight on the display, and know what parameters you are testing with the backlit illuminated dial.

Take measurements more safely with one hand using the single test lead holder. Test leads come with removable gold plated tips to connect with Fieldpiece accessory heads.

The SC660 clamp meter is built to withstand the rigors of HVACR field work with high impact plastic and a display you can read in very hot or very cold environments.

What's Included

- SC660 Wireless Clamp Meter
- ADLS2 Deluxe Test Leads Kit
- ASA2 Alligator Clips
- 2 ATB1 Type K Thermocouples
- 2 Velcro Straps
- 9V Alkaline Battery (Not installed)
- ANC7 Protective Padded Case
- Operator's Manual

Quick Start

1. For electrical testing, connect test leads to black "COM" and red "+" jacks.
2. Rotate the dial to your desired measurement.
3. Connect to test points and read measurement.
4. For temperature testing, remove test leads, slide TEMP switch to the right and connect Type K thermocouples.

Certifications



UL 61010-1, Third Edition



EN61010-1, EN61010-2-032
EN61010-2-033, EMC EN61326-1



FCC ID: VEARF915A



C-Tick (N22675)



WEEE

CATIII 600V, class II and pollution degree 2 indoor use comply with CE, RoHS compliant.

CATIII is designated for measurements performed in the building installation.

Specifications

Display: 10000 count dual display

Backlight: 5 minute duration with auto-off. Blue color

Overrange: (OL) or (-OL) is displayed

Measurement rate: 3.3 times per second, nominal

Zero: Automatic

Operating environment: 32°F to 122°F (0°C to 50°C) at <70%RH

Storage temperature: -4°F to 140°F (-20°C to 60°C), 0 to 80%RH (with battery removed)

Accuracy: Stated accuracy @ 73°F±9°F (23°C±5°C), <75%RH

Temperature coefficient: 0.1 x (specified accuracy) per °C [0°C to 19°C (32°F to 66°F), 28°C to 50°C (82°F to 122°F)]

AP0 (Auto Power Off): Approx. 30 minutes

Power: Single standard 9-volt battery, NEDA 1604, JIS 006P, IEC 6F22

Battery life: 100 hours typical alkaline

Low battery indication: Battery icon blinks and "batt" is displayed when the battery voltage drops below the operating level

Dimensions: 287.5mm(H) x 79.5mm(W) x 50.0mm(D)

Weight: Approx. 450g including battery


Altitude: Up to 6562 ft (2000m)

Overload protection: 600VDC or 600VAC rms unless otherwise stated

Test leads: Use UL listed test leads that comply to UL61010-031 rated CATIII 600V or above. Included test leads are gold-plated and have removable safety caps.

Please operate the instrument following all instructions of the operator's manual to avoid impairing the safety of the product.

Measurements Dial



The SC660 is loaded with the measurement parameters essential for HVACR professionals. Select the parameter on the dial you want to measure with the rotating selector switch.

Buttons



Illuminate backlight. Press for 1 second to zero Amps DC.



Activate Inrush AAC capture mode.



Press for 1 second to connect to compatible Fieldpiece wireless tools.

Activate and cycle through Hold, Maximum, minimum, and real-time measurements. Press for 1 second to clear and exit. Press to log measurements in Job Link™.











Deactivate autoranging and move the decimal point as desired.




Cycle through displayed values on applicable switch positions. Press for 1 second to toggle °F and °C.



Display Icons

	Battery Life Monitor
	Auto Power Off Enabled
	High Voltage Warning (>30VAC/VDC)
	Manual Ranging
HOLD	Data Hold
MAX	Maximum
MIN	Minimum
INRUSH	Inrush AAC
	Wireless Enabled (searching if flashing)
	Wireless Signal Strength Bars
T1 T2	Temperature Inputs
T1-T2	Delta T
°F	Fahrenheit
°C	Celsius
	Continuity Test
	Diode Test
Hz	Frequency (Hertz)
%	Duty Cycle (percentage)
Ω	Resistance Test (Ohms)
F	Capacitance Test (farads)
μA	Microamps DC
n	Nano Unit (10^{-9} , one billionth)
μ	Micro Unit (10^{-6} , one millionth)
m	Milli Unit (10^{-3} , one thousandth)
K	Kilo Unit (10^3 , one thousand)
M	Mega Unit (10^6 , one million)
AC	Alternating Current
DC	Direct Current



Easy to Read Display

Easily see your measurements on the large dual lighting with the bright blue backlight to illuminate the way.

Test Parameters

Volts AC (VAC) True RMS (50-500Hz)

Test power lines (120, 220, 480VAC), test 24VAC going to controls, and test for transformer failure.

Ranges: 1000mV, 10V, 100V, 600V **Resolution:** 0.1mV

Accuracy: $\pm(1.2\% + 10)$ 1000mV, 10, 100V range
 $\pm(1.5\% + 10)$ 600V range



Minimum Input Voltage Range: >20 digits

Crest factor: ≤ 3

Audio/Visual Hi-V indicator: >30VAC/VDC

Input impedance: 5M Ω

Overload Protection: 600VDC or 600VAC rms



Volts DC (VDC)



Select VDC and measure DC voltages on circuit boards on more advanced HVACR systems and logic control boards. In ADC/VDC dial position, VDC is shown on lower display. Press SELECT button to show ADC on the top display at the same time.

Ranges: 1000mV, 10V, 100V, 600V **Resolution:** 0.1mV

Accuracy: $\pm(0.5\% + 5)$

Input impedance: 5M Ω



Overload Protection: 600VDC or 600VAC rms



Non Contact Voltage (NCV)

Use NCV to check 24VAC from a thermostat or live voltage up to 600VAC. Always test a known live source before using. A segment graph and RED LED will display the presence of voltage. An audible beep increases from intermittent to continuous as intensity of field (EF) increases.

AC Voltage Detection Range: 24VAC to 600VAC (50-60Hz)



Amps AC (AAC) True RMS (50-60Hz)

Test any isolated power line. Press SELECT once on VAC/AAC/Hz position. Read AAC in upper display and VAC on the lower display at the same time. For AAC measurements < 100AAC, select AAC switch position and for measurements > 100AAC, select the 400AAC switch position.

Range: 100A, 400A **Resolution:** 0.01A **Crest factor:** ≤ 3

Accuracy: $\pm(2.5\% + 15)$ 100A, $\pm(2.0\% + 10)$ 400A

Minimum Input Current Range: >20 digits

Overload Protection: 400AAC **Jaw Opening:** 1.2in (30 mm)

Frequency (Hz) Through Clamp

Measure Hz on variable frequency drive motors. Turn dial to either VAC/AAC/Hz and press SELECT twice. Hz will show in upper display and VAC on the lower display at the same time.


Range: 10Hz to 400Hz **Resolution:** 0.1Hz

Accuracy: $\pm(0.1\% + 5)$

Minimum current range: >10AAC (10 to 100Hz); >25AAC (100 to 400Hz) on AAC switch; >50AAC (10 to 400Hz) on 400AAC switch.

Overload Protection: 400AAC





Amps DC (ADC)

Measure ADC through the clamp jaw. Press  for 1 second to zero the ADC value in the top display.

Ranges: 100A, 400A **Resolution:** 0.01A **Jaw Opening:** 1.2in (30 mm)

Accuracy: $\pm(2.5\% + 15)$ 100A, $\pm(2.0\% + 10)$ 400A

Overload Protection: 400ADC



Inrush AAC Current

Inrush mode captures the starting amp draw of a motor. Starting amp draw can assist in diagnosing a motor before it fails.

Activate Inrush mode

- 1 Rotate selector switch to VAC/AAC/Hz or VAC/400AAC/Hz
- 2 Press SELECT once to show AAC on upper display. Press INRUSH on the right side of meter to activate.
- 3 Clamp meter around the motor's start wire. Turn motor on. The starting amp draw will hold on the upper display.
- 4 Press INRUSH to reset the test. Press INRUSH for 2 seconds to exit Inrush mode.

Inrush measurement period: 100-milliseconds

Minimum input: >2A on AAC range; >20A on 400A range

⚠ Note: AAC or Hz through the clamp and VAC through the test leads can be measured simultaneously. However, if only AAC, Frequency (Hz), or Inrush AAC is measured through the clamp, test leads and thermocouples must be unplugged from the meter.

MicroAmps DC (μ ADC)

Microamps for flame rectifier diode test on a heater control. Connect leads between flame sensor probe and control module and turn heating unit on to read μ A measurement. When the flame is on, there should be a measurable μ ADC signal, typically under 10μ ADC. Compare measurement to manufacturer's specification to determine if replacement is necessary.

Ranges: 1000μ A **Resolution:** 0.1μ A

Accuracy: $\pm(1.0\% + 5)$ **Volts burden:** 5V

Overload Protection: 600VDC or 600VAC rms

Frequency (Hz) Through Leads

Check incoming voltages to ensure they are cycling at 60Hz. For frequency measurements on VFD equipment, use the amp clamp.

Ranges: 100Hz, 1kHz, 10kHz, 100kHz, 1MHz **Resolution:** 0.01Hz

Accuracy: $\pm(0.1\% + 5)$ **Sensitivity:** 10Hz to 1MHz: $>3.5V_{rms}$

Minimum PW: $>1\mu$ s **Duty Cycle Limits:** $>30\%$ and $<70\%$

Duty Cycle (%)

Duty cycle shows the % On Time of a 5V logic signal square wave.

Ranges: 5%-95% (40Hz to 1kHz), 10%-90% (1kHz to 10kHz), 20%-80% (10kHz to 20kHz)

Accuracy (5V logic): $\pm(2\% + 10)$ **Resolution:** 0.1%

Pulse Width: $>10\mu$ s

Overload Protection: 600VDC or 600VAC rms




Capacitance (MFD)

Set to MFD to test motor start and run capacitors. Capacitors are one of the most failure prone components in a HVACR system. Disconnect from power and resistors between terminals. Discharge capacitor before testing. If dI.S.C is displayed, the capacitor needs to be fully discharged to test.

Ranges: 10nF, 100nF, 1000nF, 10 μ F, 100 μ F, 1000 μ F, 10mF

Accuracy: $\pm(3\% + 15)$ 10nF, $\pm(3\% + 5)$ 100nF to 1000 μ F, $\pm(5\% + 5)$ 10mF

Resolution: 0.01nF **Overload Protection:** 600VDC or 600VAC rms



Discharge Cap First!

Resistance (Ω)

Used for “ohming out” a compressor. A 0.01 Ω resolution is useful to test the resistance between the terminal poles because the values are typically very low.

Ranges: 100 Ω , 1000 Ω , 10k Ω , 100k Ω , 1000k Ω , 10M Ω , 50M Ω

Resolution: 0.01 Ω

Accuracy: $\pm(1.0\% + 15)$ 100 Ω , $\pm(1.0\% + 5)$ 1000 Ω to 100k Ω , $\pm(1.5\% + 5)$ 1000k Ω , $\pm(3.0\% + 5)$ 10M Ω to 50M Ω

Open circuit volts: -1.1VDC typical, -3.2VDC (100 Ω range)

Overload Protection: 600VDC or 600VAC rms

Continuity ($\bullet\bullet\bullet$)

Use the continuity feature to test if a circuit is open or closed. Use this feature to check isolated fuses as well. A steady “beep” and green LED indicate you have continuity. Press SELECT once to enter Continuity mode.

Range: 100 Ω **Resolution:** 0.01 Ω **Response time:** 100ms

Audible beep: <30 Ω

Overload Protection: 600VDC or 600VAC rms

Diode Test (\rightarrow)





Test diodes for proper forward and reversed-biased functions. Press SELECT twice to enter Diode mode.

Test current: 0.8mA (Approx.) **Accuracy:** $\pm(1.5\% + 5)$

Open circuit volts: 3.2VDC typical **Audible beep:** <0.05V

Visual Indicator: Green LED

Overload Protection: 600VDC or 600VAC rms



Dual Temperature (T1, T2, T1-T2)

Plug any Type K thermocouple directly into the meter to measure temperature. Test for proper airflow across the evaporator coil by measuring delta T with the dual temperature inputs.

Cold junction is located inside the meter and allows for accurate measurements even in rapidly changing ambient temperatures (going from rooftop to freezer). No adapter is required.

By default, T1 will show on top display and T2 on bottom display. Press SELECT button once to display T1 on top and T1-T2 on the bottom. Press SELECT button again to display T2 on top and T1-T2 on the bottom.

Range: -58°F to 2372°F, (-50°C to 1300°C) **Resolution:** 0.1°

Accuracy: $\pm(1^\circ\text{F})^* 32^\circ\text{F}$ to 120°F , $\pm(1^\circ\text{C}) 0^\circ\text{C}$ to 49°C



$\pm(1\%+2^\circ\text{F}) 32^\circ\text{F}$ to 932°F , $\pm(1\%+1^\circ\text{C}) 0^\circ\text{C}$ to 500°C

$\pm(2\%+6^\circ\text{F}) -58^\circ\text{F}$ to 32°F , $\pm(2\%+3^\circ\text{C}) -50^\circ\text{C}$ to 0°C

$\pm(2\%+6^\circ\text{F}) 932^\circ\text{F}$ to 2372°F , $\pm(2\%+3^\circ\text{C}) 500^\circ\text{C}$ to 1300°C

Sensor type: Type K thermocouple *After field calibration

Overload protection: 30 VDC or 30VAC rms



Unplug Leads and Slide TEMP Switch to the Right

Change Units (°F or °C)


By default, temperature units are set to Fahrenheit (°F). In Temperature dial position, press SELECT button for 1 second to toggle between Fahrenheit (°F) and Celsius (°C).

Temperature Calibration

For accuracies of $\pm 1^\circ\text{F}$, calibrate both thermocouples to a known temperature. A glass of stabilized ice water is very close to 32°F (0°C) and is usually very convenient but any known temperature can be used. Ideally you should calibrate to a known temperature closest to the temperatures you will be testing.

1. Rotate dial to the $^\circ\text{F}$ °C, T1-T2 position.
2. Plug one thermocouple to be calibrated into the T1 Type K jack.
3. Unscrew A and B and remove the battery cover.
4. Stabilize a large cup of ice water. Stir the ice with the water until temperature stays at a stable value.
5. Immerse the T1 thermocouple probe and let it stabilize. Keep stirring water to prevent thermocouple from direct contact with ice.
6. Use a small screwdriver to adjust calibration T1 Temp Cal pot below the battery as close to 32°F (0°C) as you would like.
7. Repeat step 2-6 and replace T2 for T1 for T2 thermocouple.

Note: J1-J2 switch is for factory calibration purposes only. Do not switch from J2.



Phase Rotation Test (L1L2, L1L3)

Connect 3-phase power lines in the correct order to the terminals of a motor to ensure the motor turns in the intended direction. Incorrect wiring can damage some equipment. The terminals on the motor are usually marked L1, L2, and L3; however, the wires supplying power usually are not. Perform a simple phase rotation test with two test leads to quickly identify the order of 3-phase power lines.

Range: 80±5 VAC to 600VAC (50Hz to 80Hz) **Resolution:** 0.1V


Accuracy: ±(1.5% rdg + 10 dgts)

Overload Protection: 600VDC or AC rms


How to Perform a Phase Rotation Test

Set Up

Switch to **L1L2** or **L1L3**. Plug black test lead into the COM (L1) port and red test lead to the VΩ (L2 L3) port on the SC660.




You will see “L1L2” blinking to indicate phase rotation test is ready to begin.



Step 1


Connect both black and red test leads to any two of the three phase voltage lines in question. The line voltage will hold on the bottom display. Blinking L1 and L2 disappear. L3 will blink on top display to indicate test is ready for Step 2.



Important: Step 2 must be performed within 5 seconds of completing Step 1 or “Err” will show and Step 1 must be repeated.

Step 2

With the black lead still on “L1”, move the red test lead to the third 3-phase voltage line. The line voltage will hold on the bottom display. The top display will show L123 indicating forward or L321 indicating reversed.



Simply swap any two lines to change the direction. You can verify this by performing the test again.




Phase Rotation Testing Tips

- 1 The measured voltage during phase rotation test must be $>80.0\pm 5VAC$. If not, the phase rotation test can not be performed and "Err" will show on the top display.
- 2 After phase rotation test is complete, press SELECT button to begin a new phase rotation test.
- 3 Be sure to connect test leads to 3-phase voltage lines for at least 2 seconds until voltage reading holds on the bottom display
- 4 Phase rotation test cannot be performed on Hi-frequency voltage signals. Be sure voltage lines are within 50-80Hz to perform the phase rotation test.

Modular Expandability

Your SC660 is compatible with Fieldpiece Accessory Heads. With Fieldpiece Accessory Heads, you can measure any available parameter, and read the measurement on your new meter's display in real-time, Hold, Max, and min.

Rotate the selector to VDC and stay in mV range. Remove the probe tips of your test leads, and connect your accessory head (model AAV3 shown).



Visit www.fieldpiece.com to see all of the different Accessory Heads that Fieldpiece offers.

Wireless Receiver Mode

Use your SC660 to wirelessly receive live measurements from Fieldpiece wireless tools from anywhere on the jobsite. For example, receive an evaporator delta T measurement to your SC660 while you work at the condenser outdoor unit.

Receiving Wireless Measurements

- 1 Select RECV (📶) switch position on SC660.
- 2 Press SYNC button for 1 second until meter beeps. Signal strength bars indicate wireless search.
- 3 Hold SYNC button for 1 second on the Fieldpiece wireless transmitter.
- 4 The wireless measurement, signal strength, and battery life of the wireless transmitter will display in the top-right corner of the SC660 screen.

Note: If a Fieldpiece wireless transmitter is not connected within 2 min, the SC660 will beep and stop searching.

Wireless Auto-Connection

When powered on, SC660 will search for the last connected single-link wireless partner. If found, SC660 will automatically reconnect. If not found, wireless will stop searching after 2 minutes and an audible beep will sound.

Log Measurements in Job Link™

Keep your hands free to focus on the job. Press the HOLD button on your clamp meter to log measurements within Job Link mobile app.

Wireless Transmitter Mode

The SC660 is Fieldpiece Job Link™ compatible*. Send electrical measurements wirelessly from SC660 to the Job Link™ mobile app via the JL2 Transmitter .

Sending Wireless Measurements

- 1 Select any switch position other than RECV (📶) on SC660.
- 2 Press SYNC button for 1 second until meter beeps. Signal strength bars indicate wireless search.
- 3 Hold SYNC button for 1 second on the Fieldpiece JL2 Job Link™ Transmitter.
- 4 Follow instructions for Job Link™ mobile app.

Wireless Specifications

Wireless range: Up to 75 feet (23m) line of sight

Minimum wireless distance: 1 foot (30cm)

Wireless frequency: 910MHz to 920MHz (US), 868.1MHz to 868.5MHz (European)

Wireless Compatibility



For Receiving Wireless Measurements: EH4W, ET2W, LT17AW, SC57, SC660, SC460

For Sending Wireless Measurements: JL2 Job Link™ Transmitter, SC460 or SC660.




Job Link Note: Some electrical parameters may take up to 30 seconds to be visible within the Job Link Live measurements screen on your mobile device.

Functions

Auto Power Off

Auto power off or APO will automatically turn off your meter after 30 minutes of inactivity. By default it is activated and APO will show on the display. To disable, turn meter off. Hold  and power on the meter by turning the selector dial to any range. Release  after the beep. APO will no longer display over the battery icon.

Hold/Max/min

Press  to cycle through Hold, Maximum, minimum, or real-time measurements. When MAXMIN is displayed, you are seeing the real-time measurement, but Max and min values are still being recorded. Press  for 1 second to clear and exit. Press  to log an SC660 measurement in Job Link mobile app. See Wireless Section for Job Link compatibility details.

High Voltage Warning

The ⚡ symbol will display when measuring >30VAC/VDC. An audible beep will be heard and red LED will be shown.



Battery Replacement

When your meter's battery is low, the battery icon will appear empty and blink for 30 seconds. "LO.bT" will display and meter will power off.


Turn dial to OFF position, disconnect test leads and remove the battery cover with magnet strap on the back of your meter. Remove old battery and replace with a standard 9V battery only. Be sure to re-insert the magnet strap before re-installing the battery cover.

Backlight Illumination

See your measurements in dark environments.

Press  to illuminate the display and the selector dial. Illumination will stay on for 5 minutes before turning off automatically. Illumination can be turned off at any time by pressing .

Manual Ranging

Press  to disable auto-ranging and set your clamp meter to a specific range. Manual ranging applies to VAC, AAC, VDC, ADC, Hz, MFD, and resistance (Ω). Press for 1 second to exit manual ranging and return to auto-ranging.

Safety Information

Never ground yourself when taking electrical measurements. Do not touch exposed metal pipes, outlets, fixtures, etc., which might be at ground potential, while taking measurements. Keep your body isolated from ground by using dry clothing, rubber shoes, rubber mats, or any approved insulating material.

Disconnect the test leads before opening the case. Inspect the test leads for damage to the insulation or exposed wire. Replace if suspect. Keep your fingers behind the finger guards on the probes while taking measurements.

When disconnecting from a circuit, disconnect the "RED" lead first, then the common "BLACK" lead. Use one handed testing when possible. Work with others.

Turn off power to the circuit under test before cutting, unsoldering, or breaking the circuit.

Do not measure resistance (ohms) when circuit is powered. Isolate load by disconnecting from circuit.

Disconnect the meter from circuit before turning any inductor off, including motors, transformers, and solenoids. High voltage transients can damage the meter beyond repair.

Do not use during electrical storms.

Do not apply more than rated voltages between input and ground.





Isolate capacitors from system and discharge them safely before testing.

Temperature switch prevents leaving thermocouple plugged in while measuring voltage.

When measuring high frequency AC current, do not exceed the rated 400AAC of the clamp. Failure to adhere may cause the clamp to heat up dangerously.

All voltage tests: All voltage ranges will withstand up to 600V. Do not apply more than 600VDC or AC rms.

Symbols used:

-  Caution, risk of electric shock
-  Caution, refer to manual.
-  Ground
-  Double insulation

WARNINGS

DISCONNECT AND UNPLUG TEST LEADS before opening case.
TEST NCV FUNCTION ON KNOWN LIVE WIRE before using.
DO NOT APPLY VOLTAGE greater than 30VAC/VDC to the thermocouple or the jacks when the rotary dial is on °F°C. (Use only Type K thermocouples)
DO NOT APPLY VOLTAGE TO THE JACKS when the rotary dial is on microamps. Even low voltages can cause a current overload and potentially harm the meter.

FCC Compliance and Advisory Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, according to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- 1.Reorient the receiving antenna.
 - 2.Increase the separation between the equipment and receiver.
 - 3.Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - 4.Consult the dealer or an experienced radio/TV technician for help.
- Shielded interface cables must be used in order to comply with emission limits.

FCC Caution: To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Fieldpiece
Designed in USA
MADE IN TAIWAN

Limited Warranty

This meter is warranted against defects in material or workmanship for one year from date of purchase from an authorized Fieldpiece dealer. Fieldpiece will replace or repair the defective unit, at its option, subject to verification of the defect.

This warranty does not apply to defects resulting from abuse, neglect, accident, unauthorized repair, alteration, or unreasonable use of the instrument.

Any implied warranties arising from the sale of a Fieldpiece product, including but not limited to implied warranties of merchantability and fitness for a particular purpose, are limited to the above. Fieldpiece shall not be liable for loss of use of the instrument or other incidental or consequential damages, expenses, or economic loss, or for any claim of such damage, expenses, or economic loss.

State laws vary. The above limitations or exclusions may not apply to you.

Obtaining Service

Email Fieldpiece warranty department at fpwarranty@fieldpiece.com for current fixed price repair service. Send check or money order made out to Fieldpiece Instruments for the amount quoted. If your meter is under warranty there will be no cost for the repair/replacement. Send your meter, freight prepaid, to Fieldpiece Instruments. Send proof of date and location of purchase for in-warranty service. The meter will be repaired or replaced, at the option of Fieldpiece, and returned via least cost transportation.

For international customers, warranty for products purchased outside of the U.S. should be handled through local distributors. Visit our website to find your local distributor.

© Fieldpiece Instruments, Inc 2016; v14